

Valid from firmware version: V1.0

CHANNEL	VALUE	FUNCTION
7ch		
1	000-007	CCT
	008-048	6000K
	049-089	5600K
	090-130	5000K
	131-171	4500K
	172-212	4000K
	213-255	3200K 2700K
2	000-007	COLOR WHEEL
	008-016	Open
	017-025	Color 1
	026-034	Color 2
	035-043	Color 3
	044-052	Color 4
	053-063	Color 5
	064-127	Color 6
	128-189	Open
	190-193	Clockwise Rotation, Fast to Slow
	194-255	Stop
		Counter-Clockwise Rotation, Slow to Fast
3	000-015	MINUS GREEN
	016-031	0
	032-047	1/2
	048-063	1/4
	064-255	1/8 Null
4	000-255	ZOOM Narrow→Wide
5	000-255	FOCUS 0%→100%
6	000-007	STROBE
	008-015	Close
	016-131	Open
	132-139	Strobe from Slow to Fast
	140-181	Open
	182-189	Fast Open Slow Close from Slow to Fast
	190-231	Open
	232-239	Slow Open Fast Close from Slow to Fast Open

	240-247 248-255	Random Strobe from Slow to Fast Open
7	000-255	DIMMER 0%→100%

