

CHANEL		VALUE	FUNCTION
23ch (RGB)	23ch (CMY)		
1	1	000-255	PAN 0°→540°
2	2	000-255	PAN FINE
3	3	000-255	TILE 0°→250°
4	4	000-255	TILT FINE
5	5	000-255	PAN/TILT SPEED Fast to slow
6		000-255	RED 0%→100%
7		000-255	RED FINE 0%→100%
8		000-255	GREEN 0%→100%
9		000-255	GREEN FINE 0%→100%
10		000-255	BLUE 0%→100%
11		000-255	BLUE FINE 0%→100%
	6	000-255	CYAN 0%→100%
	7	000-255	CYAN FINE 0%→100%
	8	000-255	MAGENTA 0%→100%

	9	000-255	MAGENTA FINE 0%→100%
	10	000-255	YELLOW 0%→100%
	11	000-255	YELLOW FINE 0%→100%
12	12	000-255	CTO 8000K-2500K
13	13	000-007	Color Null
		008-009	010 Medium Yellow
		010-011	019 Fire
		012-013	021 Gold Amber
		014-015	025 Sunset Red
		016-017	036 Medium Pink
		018-019	052 Light Lavender
		020-021	058 Lavender
		022-023	068 Sky Blue
		024-025	079 Just Blue
		026-027	088 Lime Green
		028-029	089 Moss Green
		030-031	090 Dark Yellow Green
		032-033	100 Spring Yellow
		034-035	101 Yellow
		036-037	102 Light Amber
		038-039	103 Straw
		040-041	104 Deep Amber
		042-043	105 Orange
		044-045	111 Dark Pink
		046-047	115 Peacock Blue
		048-049	116 Medium Blue-Green
		050-051	117 Steel Blue
		052-053	118 Light Blue
		054-055	120 Deep Blue
		056-057	121 LEE Green
		058-059	122 Fern Green
		060-061	124 Dark Green

		062-063 064-065 066-067 068-069 070-071 072-073 074-075 076-077 078-079 080-081 082-083 084-085 086-087 088-089 090-091 092-093 094-095 096-097 098-099 100-101 102-103 104-105 106-107 108-109 110-255	126 Mauve 128 Bright Pink 132 Medium Blue 135 Deep Golden Amber 136 Pale Lavender 137 Special Lavender 138 Pale Green 139 Primary Green 141 Bright Blue 147 Apricot 152 Pale Gold 157 Pink 162 Bastard Amber 164 Flame Red 165 Daylight Blue 170 Deep Lavender 181 Congo Blue 194 Surprise Pink 197 Alice Blue 201 Full C.T. Blue 202 Half C.T. Blue 353 Lighter Blue 778 Millennium Gold Amber Null
14	14	000-007 008-127 128-255	Prism Tab 1 Off Prism 1 Prism 2
15	15	000-127 128-189 190-193 194-255	R-Prism 1 Index 0°~360° Clockwise Rotation, Fast to Slow Stop Counter-Clockwise Rotation, Slow to Fast
16	16	000-007 008-127 128-255	Prism Tab 2 Off Prism 3 Prism 4

17	17	000-127 128-189 190-193 194-255	R-Prism 2 Index 0°~360° Clockwise Rotation, Fast to Slow Stop Counter-Clockwise Rotation, Slow to Fast
18	18	000-255	FOCUS 0%→100%
19	19	000-255	FOCUS FINE
20	20	000-007 008-015 016-131 132-139 140-181 182-189 190-231 232-239 240-247 248-255	STROBE Close Open Strobe Slow->Fast Open Fast Open Slow Close Open Fast Close Slow Open Open Random Strobe Slow >Fast Open
21	21	000-255	DIMMER 0%→100%
22	22	000-255	DIMMER FINE 0%→100%
23	23	000-029 030-039 040-049 050-059 060-069 070-079 080-089 090-099 100-109 110-119 120-139 140-149	FUNCTION No Function Dimmer Curve Linear Dimmer Curve Square Law Dimmer Curve Inv Square Law Dimmer Curve S Fan Mode Auto Fan Mode Quiet Fan Mode Super Quiet No Function No Function No Function Pan/tilt Reset

		150-159	Effect Reset
		160-199	No Function
		200-209	Reset all
		210-219	Dimmer Speed Fast
		220-229	Dimmer Speed Smooth
		230-239	No Function
		240-241	No Function
		242-243	Sun Protection Mode: On
		244-245	Sun Protection Mode: Off
		246-255	No Function