NLP accesories
NLP series
NLP components



The **NLP components** are various **cables, E-STOP cables** and **center rings** that are necessary for the **NLP system** to work.

The amount of each of these components depends on the **size of the project and installation**. Ask for our assistance when you are interested in this product.

- Link **cables**
- **E-STOP cables**
- **Center rings**

Variants

Cables 5-pin Neutrik male to female

- *968021* NLP-CABLE-10m Length: 10 meters
- *968022* NLP-CABLE-20m Length: 20 meters
- *968023* NLP-CABLE-30m Length: 30 meters
- *968024* NLP-CABLE-40m Length: 40 meters
- *968025* NLP-CABLE-50m Length: 50 meters

E-STOP button with 4-pin Neutrik cable

- *968012* NLP-E-STOP-1M Length: 1 meter
- *968026* NLP-E-STOP-2M Length: 2 meters
- *968029* NLP-E-STOP-5M Length: 5 meters

SRS Group s.r.o reserves the right to make changes to the equipment described in this manual/datasheet without prior notice. (E&OE). © SRS Group s.r.o

SRS Group s.r.o.
Pri majeri 4, 831 07 Bratislava, Slovakia
phone: +421 232 661 800, email: sales@srs-group.com, www.srs-group.com

SRS Group s.r.o reserves the right to make changes to the equipment described in this manual/datasheet without prior notice. (E&OE). © SRS Group s.r.o

SRS Group s.r.o.
Pri majeri 4, 831 07 Bratislava, Slovakia
phone: +421 232 661 800, email: sales@srs-group.com, www.srs-group.com