UltiSense
NDP series
NDP software



UltiSense is a JAVA based **monitoring software** that is used to manage network & dimmer properties of the **NDP series** dimmer packs. It is **freely downloadable** for all users of the **NDP series** dimmers. Even though the **NDP series** dimmer pack features a **multi-functional menu** with an encoder and two buttons, and can therefore work without a computer perfectly, the **UltiSense** software makes its operation even **smoother and more organized**.

The **UltiSense software** shows the status of the following parameters:

- **DMX inputs**
- **Network input**
- **All input voltages**
- **Temperature**

The following dimmer parameters can be edited using the **UltiSense software**:

- **Preheat**
- **Curves**
- **Output limits**
- **Channel names**

- Free **JAVA based monitoring software**
- **Windows / Mac / Linux OS** compatible
- **Manages network & dimmer** properties
- **Built-in Art.Net** console
- **Clone / Edit / Erase** of settings

Optional features (depend on hardware):

- **Current sensing feedback**
- **Overload check** for each channel

SRS Group s.r.o reserves the right to make changes to the equipment described in this manual/datasheet without prior notice. (E&OE). © SRS Group s.r.o

SRS Group s.r.o.
Pri majeri 4, 831 07 Bratislava, Slovakia
phone: +421 232 661 800, email: sales@srs-group.com, www.srs-group.com